





FS1208



EXPLODED VIEW



Parts

1.	Chamber
2.	Barrel Cap
3.	Pellet Holder
4.	Safety Base
5.	Barricade
6.	Trigger & Twist Spring
7.	Outlet Hammer
8.	Slid Axle
9.	C-Clip
10.	Barrel & C-Clip
11.	Slid Axle & Barrel
12.	Spring
14.	Safety Switch Kit
15.	Locking Screw
17.	Puncture Lever
18.	Bar
19.	Magazine Spring
20.	Magazine Housing
21.	Grip Piece
22.	Grip Piece
23.	Right Frame
24.	Left Frame

